

Operation and Maintenance

PS and PS - F Series

C O N T E N T S

| | Page |
|----------------------------|-------|
| INTRODUCTION | 1 |
| UNPACKING AND INSPECTION | 1 |
| PRECAUTIONS FOR OPERATION | 1 - 3 |
| MAINTENANCE AND INSPECTION | 3 |
| PREVENTIVE MAINTENANCE | 4 - 5 |
| DISASSEMBLY AND ASSEMBLY | 5 - 6 |

1. INTRODUCTION

You are kindly requested to read this manual carefully before unpacking and installing the Pump.

2. UNPACKING AND INSPECTION

Check following points and if any are incorrect, please refer to your supplier.

- 1) Does the description on the nameplate comply with your order?
- 2) Are all items delivered?
- 3) Is there any damage to the pump or /and parts caused by an accident during transport?
- 4) Are all bolts tightened?

3. PRECAUTIONS FOR OPERATION

※Do not operate the pump without positive pressure!

As the abrasion parts are cooled by the pumped liquid, operation without positive pressure or with mis-operation , such as the suction valve closed may damage the internals of the pump.

If the pump has been running in these kinds of circumstances or without liquid at all, do not Prime the pump with any liquid, but allow the pump to stand and cool down for at least one hour. Priming the pump too soon may result in a thermal shock.

※Influence of liquid temperature

The performance of the pump is not affected by any change in temperature. Liquids may change in viscosity, vapors pressure, corrosiveness, etc when the liquid temperature changes.

Therefore it is necessary to the change in characteristics of the liquid being pumped.

Operating temperature of liquids pumped (max range for clean water) 0 to 70°Cfor PS series,

0 to 90°C for PS-F series. Ambient temperature range 0 to 40°C

※Change in performance due to specific gravity but viscosity.

- 1) Power requirement is increased by specific gravity but pump performance is not affected.
- 2) More viscosity affect pump performance and power requirement, therefore it's necessary to calculate modified pump performance & modified power requirement in advance.

3) Preparations before operation

- (1) Clean the inside of the piping and tanks completely before installs the pump.
- (2) Retighten the flange connection bolts and base mounting bolts
- (3) Turn the motor fan by screwdriver and check that it turns freely.
- (4) Prime the pump and verify that the pump is filled with liquid.
- (5) Completely close the discharge valve.
- (6) Turn the motor fan by using a screwdriver to expel remaining air from the impeller.
- (7) Verify the direction of rotation of the pump. (C·C·W·from front view)

When in reverse of exchanges the connection of two phases of the three phase power supply.

4) Precautions during operation

- (1) To operate the pump, close the discharge valve and start the pump. If the pump does not operate, Please check the wiring carefully and correct the fault.
- (2) After the pump is put in operation, gradually open the discharge valve. Use a flowmeter and pressure gauge to make sure that the pump is running under your required specification. Check also the differential head of between discharge line and suction line by indication of the discharge and suction pressure gauge.

5) Cease of operation

- (1) Gradually close the discharge valve. Do not close the discharge by using a solenoid valve or in another quick way. In the event of long discharge piping, the pump is likely to be damaged due to waterhammer on closing the discharge too quickly.
- (2) Switch off the motor. Check whether the motor stops smoothly. If not, inspect the internals of the pump.
- (3) When the operation of the pump is stopped for a long period or the liquid is likely to freeze, or crystallize, be sure to drain all the liquid from the pump and the piping.
- (4) When a power failure occurs, the power switch turned off immediately.

4. MAINTENANCE AND INSPECTION

- (1) Verify that the pump is running without vibration or any abnormal noise.
- (2) Inspect the suction tank for liquid level and the suction pressure.
- (3) Check the discharge pressure, flowrate and motor current during operation. Then please compare with the pump data to check if the pump operating condition is normal.
- (4) If a stand-by pump is installed, operate it from time to time to make sure it can operate at any time.

5. PREVENTIVE MAINTENANCE

Preventive Maintenance should be done annually.

The following items should be checked. Inspection of items for overhaul should be taken in reference to the following table:

| <u>PARTS</u> | <u>INSPECTION ITEMS</u> | <u>MEASURES</u> |
|----------------|--|-----------------------------------|
| Magnet housing | Evidence of rubbing is the housing fixed in the correct position on the shaft? | Peruse the cause rectify position |
| Rear Casing | Evidence of rubbing on the inner surface | Replace |
| | Evidence of cracking on the liquid and surface | Replace |
| | Check if there are scratches on the bottom of the rear casing | Replace |
| | Check O-ring for wear creeping and corrosion | Replace |
| Magnet Capsule | Evidence of scrub on the end part and cylindrical housing | Peruse the cause |
| | Evidence of cracks in the plastics end face and/or cylindrical housing | Replace Magnet Capsule |
| | Blockage of the passage around inner surface | Clean internal |

| | | |
|----------|---|---|
| Impeller | Existence of traces of cavitation | Peruse the cause and clean |
| | Contamination and clogging on the blades surfaces | Peruse the cause and clean |
| | Dimensional change of width | Peruse the cause and clean the impeller |

6. DISASSEMBLY AND ASSEMBLY

The magnets used to transmit motor power sufficiently, Please handle with care the at traction between the drive and driven magnets during disassembly and assembly.

Completely close both discharge and suction valves before assembly.

Be very careful when you pump corrosive liquids. There may be a residue in the pump even after a long flushing. Always wear protective clothing and masks when handling contaminated or corrosive liquids.

1) Disassembly


- (1) Drain the liquid from the pump. At this time completely flush the inside of the pump.
- (2) Remove the bolts from the front casing and remove the front casing from the bracket.
- (3) Pull the impeller forward for removal.

Careful handling of each part should ensure that no damage can occur.

- (4) Pull the rear casing forward for removal.

2) Assembly

- (1) Assemble the pump in the reverse order to disassembly.
- (2) Before assembly clean all parts so that no foreign particles are present in or around the parts. Make sure that the parts are not scratched and that the magnets are not contaminated with metallic particles.
- (3) Always mount new O-rings after disassembly.
- (4) Tighten all bolts equally and make sure they are not over tightened.



1. Discharge pipe
2. Valve
3. Non-return valve
4. Pressure gauge
5. Pump
6. Vacuum gauge
7. Absorbent pipe
8. Pipe support
9. Absorbent pipe shock absorber support
10. Screen
11. Reservoir
12. Bottom valve